

Methodology

1. Minimum 4 pilot vehicles required to facilitate contra flow movement.
2. Road Network Operations Centre shall be contacted (138 111) prior to commencing the contra flow movement and at the conclusion of the contra flow movement.
3. Direct UHF radio communication is to be maintained between Pilot vehicles, Oversize vehicle(s) and Traffic Escort Warden at all times.
4. Pilot vehicles shall move to the following locations shown below:
 - Pilot vehicle 1 is to stop all southbound traffic on South Western Highway
 - Pilot vehicle 2 is to stop all northbound traffic on South Western Highway
 - Pilot vehicle 3 is to stop all traffic exiting from Hay Road
 - Pilot vehicle 4 is to stop all eastbound traffic on Thomas Road
5. Oversize vehicle(s) shall not commence contra flow movement until notified that all traffic is stopped and the contra flow is clear of traffic.
 - Oversize vehicle(s) shall cross into the westbound lane(s) on Thomas Road and commence contra flow to South Western Highway.
 - Pilot vehicle 4 to remain in westbound lane on Thomas Road and travel behind Oversize vehicles(s) with traffic in tow.
6. Pilot vehicle 4 to hold westbound traffic at intersection of Thomas Road and South Western Highway whilst Oversize vehicle(s) complete contra flow movement (northbound or southbound) and return to their natural lane of travel.
7. Once the Oversize vehicle(s) return to their natural lane of travel, Pilot vehicles can release traffic and continue with duties as required.

Wongong S Rd

Pilot ④

Thomas Rd

Butcher Rd

Hay Rd

Pilot ③

South Western Hwy

Pilot ①

Pilot ②



Title:
OVERSIZE VEHICLE MOVEMENT – THOMAS ROAD / SOUTH WESTERN HIGHWAY CONTRA FLOW ROUTE

Legend	
	Train Tracks
	Pilot Vehicle
	Oversize Vehicle Direction

TGS NO.:
OSOM 2023 - 01

Revision:
0

Version Date :
9 September 2023

Scale
Not to Scale

